

Manual Supplement

Manual Title:	Ti9, Ti10, Ti25, TiRx, TiR and TiR1 Users		
Part Number:	2803044	Supplement Issue:	2
Print Date:	August 2007	Issue Date:	2/11
Revision/Date:	2, 8/10	Page Count:	1

This supplement contains information necessary to ensure the accuracy of the above manual.

Change #1,

On page 14, following **Making Accurate Temperature Measurements** add:

Note

All thermal imagers require appropriate warm-up time in order to obtain the most accurate temperature measurement and best image quality. This time can often vary by model and by environmental conditions. Although most imagers are fully warmed-up within 3-5 minutes, it is always a best practice to wait at least 10 minutes if the most accurate temperature measurement is critical to your application. Whenever changing or adding optional lenses, additional stabilization time may be required depending on the situation.